

Item No. 853739 - ProClip Center Mount

x2
GAP OPENER

ProClip[®]
mobile mounting solutions
INSTALLATION INSTRUCTIONS

Compatible with:

BMW 3-series/M3 2005 - 2011 (EU) | BMW 3-series/M3 2006 - 2011 (US) | BMW 3-series/M3 Convertible 2006 - 2012 (EU) | BMW 3-series/M3 Convertible 2007 - 2012 (US)

ONLY for models with Wood Grain and Carbon Fiber Trim. NOT for models with factory Navigation System.



Warnings:

Carefully read all instructions and review the images before attaching.

Do not attach anything to the mount until after attaching the mount to the dashboard. Doing so makes it more difficult to attach the mount to the dash. **Please note:** If you screw into the mount it will be considered used and therefore non-refundable.

The ProClip mount and/or holder in the installation pictures may look slightly different from the one you have received. However, the same instructions apply. If you have questions call our customer service at **1-800-296-3212** or **+1-847-388-7171**.

ProClip USA, Inc. may not be held liable for any personal injury or damage to a vehicle or device, resulting from accident or improper use or installation, before, during or after the installation or removal of this mount and/or holder.



1. Press the thin end of the enclosed gap openers upwards into the gap between the wood grain trim and the climate control panel frame, to widen the gap. Peel off the cover of adhesive tape on the ProClip.



2. Place/hook the grooved edge on the lower part of the ProClip into the gap between the gap openers.



3. Press forward on the upper part of the ProClip so the angled edge snaps over the wood grain trim and into the gap between the trim and the padded part of the dashboard. Press until you see or hear/feel it snaps into place. Pull out the gap openers



4. The ProClip is in place.